


Wide band Tx & Rx for Yaesu FTM-10E

1- Remove top Cover of main unit and position set so that the large square microprocessor is in the top right hand corner.

2 - To the left of this microprocessor, remove the 0 Ohm shorting link, (this looks like a surface mount resistor) as shown in the photo.

3 - Reset the radio using the method shown in the owners manual, and radio should now operate over Tx & Rx VHF 140-174Mhz & UHF 430-470Mhz



Remember it is Illegal to transmit out of band. This Modification is for Informational purposes ONLY. Doing such modifications on your radio may void any warranty and damage your equipment. All mods found on this database are offered to me by other amateur radio hams or captured by Packet system. KB2LJJ take no responsibility or liability for any damage done resulting from any modification.

ATTENTION The KB2LJJ takes no responsibility for any damage during the modification or for any wrong information made on this modification.